
Appendix: SMC Digital Flow Switch Settings

Below are the settings that were entered at Angstrom Engineering's facility prior to the shipment of the system. See the SMC Digital Flow Switch Operation Manual in the System component information section of this manual for further information. Note that output one is utilized typically as the switching input to the PLC. For ease and less confusion all switch points are set to the same value.

Setting Description	Setting	Symbol
Display Mode	Instantaneous	d_1
Display Unit	gal(us)/min	U_2
Output Method Setting	Instantaneous	o10
Output Mode Setting	Non-Reverse Output	1_P

Instantaneous Flow Rate Setting Mode F_1